



CROSS-R/RV TECHNICAL DATA


TAPPING CENTRES AND BRACKETS




CROSS-R 70-80




CROSS-R 70-144




CROSS-R2 70-168




CROSS-R 70-104




CROSS-R2 83-144




CROSS-R3 70-168



CROSS-R 137-60



CROSS-RD 137-60



CROSS-R2 177-68


E.H.E.: Sleeve for Electric Heating Element (on request)

CROSS-R 177-68


CROSS-RD 177-68

CROSS-2R 177-68


CROSS-2R 177-68
CROSS-3R 177-68
CROSS-4R 177-68




BRACKETS POSITION




CROSS-RV 68-104




CROSS-RV 68-144



CROSS-RV ...-48



CROSS-RV ...-56



CROSS-RV ...-64